



Movastop Parking Facility

Installation Guide

CODE: 119122

IMPORTANT: Only install the Movastop parking facility after the Movastop has been installed onto the door frame and cut to the correct length in accordance with the Movastop fitting guide.

As the Movastop can be cut to size exact measurements for the spacings of the parking can not be given.

The following will guide you through the installation procedure in 3 simple steps

1. Lock the Movastop into position in the locking wall plate. Offer up to the wall in the required position and mark the 4 fixing points, drill the wall and fix the locking plate into position. [FIG 1]

2. Offer up the parking shoe to the bottom of the Movastop and mark the position. [FIG 2]

3. Measure 13mm down from the marked line and reposition the parking shoe and mark the fixing points. [FIG 3]. Drill the wall and fix the parking shoe into position.

