

## Hipac Anti-fatigue Mats - Hipac Eco-Pro Mat



FAILURE TO FOLLOW CARE INSTRUCTIONS WILL VOID YOUR WARRANTY.

After unpacking your mat, you may notice small wrinkles on the outer edges of the mat and possibly some on the top surface. These are normal and should disappear within 48 hours of placing the mat on a flat surface. Your mat requires a minimal care, but certain activities should be avoided to extend the product's lifespan.



**DO NOT** stand on the mat in stiletto-style high-heeled shoes. These sharp heels can potentially damage the surface of the mat.



**DO NOT** clean with a power vacuum cleaner. The high speed rotating brush can damage the surface of the mat.



DO NOT ALLOW WATER/MOISTURE TO BECOME TRAPPED UNDER YOUR HIPAC ECO-PRO MAT. Only use on dry floors. Moisture or liquid that becomes trapped under your mat may not dry and must be removed as soon as possible to avoid damage to your flooring. When mopping your floor, please ensure that your floor has completely dried before replacing the mat. Prolonged exposure to moisture/liquid may cause mold/mildew and/or damage to your mat and some types of flooring surfaces

**CHECK** under your mat(s) periodically. We recommend that you contact your flooring provider/installer to determine if your flooring may interact with our product.

Clean your Eco-Pro mat with water, mild soap and a damp sponge, cloth or mop. You may use general purpose floor or kitchen cleaner such as 409 or mild dish-washing soap to clean your mat.



**DO NOT USE** any cleaning product containing acetone, alcohol, bleach or ammonia on your mat. These cleaning agents will VOID YOUR WARRANTY and DAMAGE YOUR MAT.

For in-hospital environments, Hipac Eco-Pro Mats may be cleaned with a low level, hospital grade disinfectant cleaner which kills blood-borne pathogens. We recommend using 3M or Ecolab HB Quat Disinfectant Cleaner, diluted and dispensed as prescribed in the cleaner's general use directions, or a cleaning agent similar in composition. You can also use BioKleen and accelerated hydrogen peroxide.



**DO NOT** use hot water extraction, steam cleaning, or high pressure, water/ air to clean the mat as they could damage the mat.



**DO NOT CLEAN** your mat in a dishwasher or any type of commercial washer.



**DO NOT** fold the mat as this can cause permanent damage.



**DO NOT** use the mat in wet environments or step on the mat with wet feet. The Hipac Eco-Pro is not intended for use in wet areas. The surface of the mat may be slippery when your feet are wet.

