

HIPAC ANTI-FATIGUE MATS

Hipac Eco-Pro Mat

Care Instructions

FAILURE TO FOLLOW CARE INSTRUCTIONS WILL VOID YOUR WARRANTY.

After unpacking your mat, you may notice small wrinkles on the outside edges of the mat and possibly some on the top surface. These are normal and should disappear within 48 hours of placing the mat on a flat surface. Your mat requires a minimum of care, but certain activities should be avoided to increase the usable life of the product.

DO NOT stand on the mat in "stiletto" type high-heeled shoes. These sharp heels can potentially damage the surface of the mat.

DO NOT clean with a power vacuum cleaner. The high speed rotating brush can damage the surface of the mat.

DO NOT ALLOW WATER/MOISTURE TO BECOME TRAPPED UNDER YOUR HIPAC ECO-PRO MAT. Only use on dry floors. Moisture or liquid that becomes trapped under your mat may not dry and must be removed as soon as possible to avoid damage to your flooring. When mopping your floor, please ensure that your floor has completely dried before replacing the mat. Prolonged exposure to moisture/liquid may cause mold/mildew and/or damage to your mat and some types of flooring surfaces

CHECK under your mat(s) periodically. We recommend that you contact your flooring provider/installer to determine if your flooring may interact with our product.

Clean your Eco-Pro mat with water, mild soap and a damp sponge, cloth or mop. You may use general purpose floor or kitchen cleaner such as 409 or mild dish-washing soap to clean your mat. **DO NOT USE any cleaning product containing acetone, alcohol, bleach or ammonia on your mat. These cleaning agents will VOID YOUR WARRANTY and DAMAGE YOUR MAT.**

For in-hospital environments, Hipac Eco-Pro Mats may be cleaned with a low-level, hospital grade disinfectant cleaner which kills blood-borne pathogens. We recommend using 3M or Ecolab HB Quat Disinfectant Cleaner, diluted and dispensed as prescribed in the cleaner's general use directions, or a cleaning agent similar in composition. You can also use BioKleen and accelerated hydrogen peroxide.

DO NOT use hot water extraction, steam cleaning, or high pressure, water/air to clean the mat as they could damage the mat.

DO NOT CLEAN your mat in a dishwasher or any type of commercial washer.

DO NOT fold the mat as this can cause permanent damage.

DO NOT use the mat in wet environments or step on the mat with wet feet. The Hipac Eco-Pro is not intended for use in wet areas. The surface of the mat may be slippery when your feet are wet.

ABOUT HIPAC

We are an Australian healthcare company that guarantees to stand behind all our medical products, both manufactured and imported, because we're here for the life of our products and clients.

PO Box 797, 36 Long St. Goulburn NSW 2580, Australia
P. +61 2 4823 0000 E. info@hipac.com.au

SYDNEY | MELBOURNE | BRISBANE | ADELAIDE | PERTH

hipac.com.au

ABN 27 600 353 688