



IVision has twice the open area compared to other panels on the market. This new and revolutionary panel gives up to 67% visibility on the 400 x 400mm panel and up to 80% visibility on a 250 x 800mm panel in its open position, and blackout in its closed state. With no mains power needed, this contemporary panel enhances any surrounding.


Size	Rectangular 254 x 804mm 254 x 404mm Square 404 x 404mm Custom sizes available
Performance	400 x 400 - 67% visibility 250 x 800 - 80% visibility
Finish	22mm Panel: 6mm toughened glass on both sides 26mm Panel: 6mm toughened glass on staff side, 10mm toughened glass on patient side. 30mm Panel: 10mm toughened glass on both sides. 39mm Panel: 10mm toughened glass on staff side, 19mm toughened glass on patient side. Optional: upgrade to toughened laminated glass e.g. 10.4mm thickness.
Ironmongery options	Standard - 8mm key, lifeline key, thumb turn / knob. Non standard - 5mm key and lever.
Fixing	As per manufacturers recommendations
Testing	Cycle tested to greater than 40,000 cycles [10 Years Typical Use].
Maintenance and Cleaning	See manufacturers recommendation.



IVision Benefits


- Monitor patients easily and safely whilst still allowing a level of privacy.
- Staff only need to carry one key to use on both Intastop Removable Doorstop and an INTAGlaze Panel (8mm standard key, Lifeline Key option available).
- Easy for staff to use whether right or left handed.
- Ensures staff and patient safety in the event of a fire by maintaining fire integrity of the door, allowing safe evacuation.
- Quiet operation (Controlled closing of glass and optional plastic key).

Cross Section Drawing and Unit Measurements



NOTE All sizes are approximate and as a guide only. Please see Operating & Maintenance manual.

Fitting Instructions and Beading



Varies to suit door thickness

NOTE different beading/intumescent required for different glass specifications.


Example of timber beading profile.

Dark State Transmission

Due to the nature of the product we cannot guarantee full blackout for the IVision panel. It provides a high level of privacy but the below light leakage does occur and we cannot get away from this.


Dark state transmission:

- ▶ 0 degree viewing: 0.002% - 0.012%
- ▶ 45 degree viewing: 0.6%





Operating Mechanism Options



Knob



Standard Key




Lifeline Key



Blank

Layout





IVision Privacy Vision Panel





Datasheet

Panel Configuration Options

Available Operator Combinations		
Knob	-	Knob
Knob	-	8mm Key
Knob	-	Lifeline Key
Knob	-	Blank
8mm Key	-	Blank
Lifeline	-	Blank

Configuration	Panel Thickness
6mm, 6mm	22mm
6mm, 10mm	26mm
10mm, 10mm	30mm
10mm, 19mm	39mm

Panel Size	
1	254 x 804
2	404 x 404



ABOUT HIPAC

We are an Australian healthcare company that guarantees to stand behind all our medical products, both manufactured and imported, because we're here for the life of our products and clients.

PO Box 797, 36 Long St. Goulburn NSW 2580, Australia
P. +61 2 4823 0000 E. info@hipac.com.au

SYDNEY | MELBOURNE | BRISBANE | ADELAIDE | PERTH

hipac.com.au

ABN 27 600 353 688