



Introduction

- Self-harm and suicide resistant hanger system
- Three models of suicide resistant clothes hangers
- Durable patented hanger-rail with no ligature points



J-Trac Coat Hanger - Standard Polyurethane

CODE: 142869

- One-piece durable and suicide resistant polyurethane hanger
- Unbreakable
- Washable



J-Trac Coat Hanger - Premium Polyurethane

CODE: 142870

- Replaceable durable polyurethane foam hanger with durable hanger fixation disc
- Low weight to reduce risk of injuries
- Washable



J-Trac Coat Hanger - Cardboard

CODE : 142868

- Replaceable cardboard hanger with durable hanger fixation disc
- Low weight to reduce risk of injuries

Product Code

Product Description

142866	J-Trac Wardrobe Rail Kit, 560mm c/w 4 Standard Coat Hangers
142867	J-Trac Wardrobe Rail Kit, 1000mm, c/w 8 Standard Coat Hangers
142868	J-Trac Coat Hanger, Cardboard
142869	J-Trac Coat Hanger, Standard Polyurethane
142870	J-Trac Coat Hanger, Premium Polyurethane Foam
144241	J-Trac Coat Hanger Disc (for Cardboard and PU Foam Hangers)
144242	J-Trac Coat Hanger w/o disc- PU Foam- Single
144243	J-Trac Coat Hanger w/o disc- Cardboard- Pack 25
144244	J-Trac Coat Hanger w/o disc- Cardboard- Pack 100



Technical Data

- 1 Hanger releases at 3.9 kg load
- 5 hangers release at 13.6 kg load
- Hanger dimensions: width - 42cm, height - 20cm

Materials

- J-Trac Hanger Cardboard - Cardboard and Polyurethane
- J-Trac Hanger Polyurethane foam - Polyurethane
- J-Trac Hanger Polyurethane - Polyurethane
- Rail and end stops - Aluminium

Mounting

1. Mount the rail with security screws.
2. Snap disc open to replace or change hanger
3. Installation manual will be provided at order or on request

Maintenance

- Rail and plastic J-Trac hanger fixation can be cleaned with alcohol or detergents.
- Cardboard J-Trac hanger can be cleaned with a dry cloth

Sustainability

- The plastic J-Trac Hangers have a very long durability.
- The plastic J-Trac Hangers are recycled as plastic, cardboard as cardboard and rail and fittings as metal

Warranty

2 Years Guarantee against all manufacturing faults.

The Cardboard Hanger is not eligible for warranty.



ABOUT HIPAC

We are an Australian healthcare company that guarantees to stand behind all our medical products, both manufactured and imported, because we're here for the life of our products and clients.

PO Box 797, 36 Long St. Goulburn NSW 2580, Australia
P. +61 2 4823 0000 E. info@hipac.com.au

SYDNEY | MELBOURNE | BRISBANE | ADELAIDE | PERTH

hipac.com.au

ABN 27 600 353 688