



Features

- Products made of lightweight and relatively soft polypropylene that cannot be made sharp.
- Rounded corners for hygiene and reduced risk of injury.
- All products release from the wall bracket at abnormal vertical load.

The products are designed to take the weight of paper towels and waste products but when additional risk force is applied they release from the bracket. The design of the wall bracket prevents the attachment of a string or similar, to create a ligature. Semitransparent material prevents the opportunity to hide objects. Interchangeable parts are easily replaced.

Materials

Polypropylene. Thickness of material: 1,5 mm.

Mounting

The wall bracket [included] is mounted with security screws.

Warranty

1 year warranty against manufacturing defects. The products have a limited life span through the design and choice of risk reducing materials, therefore no warranty is applicable.

Sustainability

Recycling as plastic

Testing

The wall bracket is flexible and durable and keeps its function after releasing 1000 cycles, tested by SP/RISE in Sweden.



Assortment

142880	Healsafe Anti-Ligature Waste Bin
142878	Healsafe Paper Towel Holder, No Lid
142879	Healsafe Paper Towel Holder, With Lid

Technical Data

142880	H 450 mm, W 270 mm, D 180 mm
142878	H 230 mm, W 240 mm, D 130 mm
142879	H 230 mm, W 240 mm, D 130 mm

Max size for paper towels: W 223 mm, D 95 mm.

ABOUT HIPAC

We are an Australian healthcare company that guarantees to stand behind all our medical products, both manufactured and imported, because we're here for the life of our products and clients.

PO Box 797, 36 Long St. Goulburn NSW 2580, Australia
P. +61 2 4823 0000 E. info@hipac.com.au

SYDNEY | MELBOURNE | BRISBANE | ADELAIDE | PERTH

hipac.com.au

ABN 27 600 353 688