

Anti-Ligature Window Curtain Tracking Kit



Features

The window curtain track is a white powder-coated aluminium track that is lightweight yet strong, and with roller runners, is ideally suited for ease of use in all hand-drawn curtain applications. Tests have shown that for anti-ligature purposes it is most important that the complete track collapses leaving no point of ligature. Even where a fixed track provides no ligature points, heavy weights can be suspended from the curtains which in turn is a serious potential risk. With the Anti-ligature window curtain tracking kit, the track and curtain together will part from the brackets under abnormal load and can then be simply and quickly reinstated.

Benefits

- built with a robust aluminium profile for consistently high performance, an excellent choice for medium to heavy curtain usage.
- offering both wall-fix and top-fix options to blend in well with any environment whilst remaining pleasing to the eye.
- with special low friction roller runners, satisfies the most demanding of environments, whether it be residential or commercial.
- secured by magnetic brackets for anti-ligature functionality.

Specification

The magnetic anti-ligature hand-drawn window curtain track as supplied by Hipac. Aluminium track with white powder-coated finish. Incorporating low friction roller runners at 16 per metre and magnetic wall-fix or top-fix brackets as necessary, spaced by manufacturer's recommendations. Fitting to be carried out by trained and accredited staff.

| Width mm | No. of Brackets |
|----------|-----------------|
| 1000 | 2 |
| 1200 | 2 |
| 1400 | 3 |
| 1600 | 3 |
| 1800 | 3 |
| 2000 | 3 |
| 2200 | 3 |
| 2400 | 4 |
| 2600 | 4 |
| 2800 | 4 |
| 3000 | 4 |

| Width mm | No. of Brackets |
|----------|-----------------|
| 3200 | 4 |
| 3400 | 5 |
| 3600 | 5 |
| 3800 | 5 |
| 4000 | 5 |
| 4200 | 5 |
| 4400 | 6 |
| 4600 | 6 |
| 4800 | 6 |
| 5000 | 6 |

Disclaimer:

All products must be fitted as per the directions detailed in the individual product Installation Instruction Document. Hipac takes no responsibility for incorrect installation/operation of the product. By purchasing this product, you are confirming that the product will be fitted as per the instructions.

Please note that Hipac offers a range of measures designed to reduce the risk of self-harm or suicide and does not offer any guarantee that it will not take place. The solutions have been designed as a deterrent only.

ABOUT HIPAC

Operating at the forefront of healthcare, we strive to redefine what's possible. We provide superior products, design expertise and total solutions to help create environments where nothing stands in the way of patient care.

Contact information



1800 75 93 93



info@hipac.com.au



www.hipac.com.au

