

K9500 Anti-Ligature Flexible Window Curtain Track



Features

The K9500 flexible window curtain track is constructed from a specially formulated plastic which is lightweight and strong and utilises self-lubricating gliders for ease of use in all hand-drawn curtain applications. Tests have shown that for anti-ligature purposes it is important that the complete track collapses leaving no point of ligature. Even when a fixed track provides no ligature points, heavy weights can be suspended from the curtains which in turn is a serious potential risk. With the K9500 the track and curtain together will part from the brackets under abnormal load and can then be simply and quickly reinstated. Only for use with lightweight curtains and where the risk of violence precludes the use of the standard K6200 aluminium track.

Benefits

- specially formulated plastic construction specially designed to be flexible enough to minimise its use as a weapon.
- suitable for lightweight curtain usage, and an excellent alternative to aluminium tracks.

- offers both wall-fix and top-fix options to blend in well with any environment whilst remaining pleasing to the eye.
- special low friction gliders to satisfy the most demanding of environments.
- secured by magnetic brackets for anti-ligature functionality.

Specification

The magnetic anti-ligature K9500 flexible hand-drawn window curtain track as supplied by Hipac. White plastic track of special flexible plastic formulation complete with gliders at a rate of 16 per metre and magnetic wall-fix or top-fix brackets as necessary, spaced in accordance with manufacturer's recommendations. Fitting to be carried out by trained and accredited staff.

Width Inches	Width mm	No. of Brackets
19 ³ / ₄	500	2
35 ¹ / ₂	900	3
51	1300	4
67	1700	5
82 ³ / ₄	2100	6
98 ¹ / ₂	2500	7
114	2900	8
130	3300	9
145 ¹ / ₂	3700	10

Disclaimer:

All products must be fitted as per the directions detailed in the individual product Installation Instruction Document. Hipac takes no responsibility for incorrect installation/operation of the product. By purchasing this product, you are confirming that the product will be fitted as per the instructions.

Please note that Hipac offers a range of measures designed to reduce the risk of self-harm or suicide and does not offer any guarantee that it will not take place. The solutions have been designed as a deterrent only.

ABOUT HIPAC

Operating at the forefront of healthcare, we strive to redefine what's possible. We provide superior products, design expertise and total solutions to help create environments where nothing stands in the way of patient care.

Contact information



1800 75 93 93



info@hipac.com.au



www.hipac.com.au

