

Anti-Ligature Coat and Towel Hook

The anti-ligature coat and towel hook has a flexible rubber part, which is fixed within a stainless steel surround and has a load release threshold. Made from a low shore rating rubber with a high silicon content and fixed by two security screws that pass through the stainless steel surround and the rubber.



Installation Description

- mark out the fixing holes using the template provided.
- drill both fixing holes and use suitable wall plugs where necessary.
- fix in place using the two security screws provided.

Operation

Designed for garments and towels up to 6kg in weight, secured using two No. 8 security screws.

Maintenance

Periodic checks should be made to ensure the fixings remain tight and that the rubber has not been damaged.

Cleaning

Cleaning of the coat and towel hook should be done with a damp cloth. Cleaning agents should be avoided.

Guarantee

10 Year Guarantee (For faulty manufacture and not for damage).

Disclaimer:

All products must be fitted as per the directions detailed in the individual product Installation Instruction Document. Hipac takes no responsibility for incorrect installation/operation of the product. By purchasing this product, you are confirming that the product will be fitted as per the instructions.

Please note that Hipac offers a range of measures designed to reduce the risk of self-harm or suicide and does not offer any guarantee that it will not take place. The solutions have been designed as a deterrent only.

ABOUT HIPAC

Operating at the forefront of healthcare, we strive to redefine what's possible. We provide superior products, design expertise and total solutions to help create environments where nothing stands in the way of patient care.

Contact information



1800 75 93 93



info@hipac.com.au



www.hipac.com.au

